



NOTES:

- POWER ASSISTED SWITCH CABIN SIGN TO BE MOUNTED ON CABINS AT SWITCH LOCATIONS DESIGNATED AS POWER ASSISTED IN THE TIMETABLE.
- 2. SIGN TO BE MOUNTED ON THE TOP OF THE CABIN FACING THE DIRECTION OF THE POINT OF SWITCH.
- 3. ON 6X6 CLMC PE FG CABINS SIGN TO BE MOUNTED ABOVE THE THERMAL GRATING.
- 4. TO BE MADE OF 0.080" 6061-T6 SHEET ALUMINUM WITH NO. 2270 SILVER SCOTCHCAL REFLECTIVE BACKGROUND AND NO. 605 BLACK SCOTCHCAL NUMERALS.

UNION PACIFIC RAILROAD ENGINEERING STANDARDS

POWER ASSISTED SWITCH CABIN SIGN

ITEM NO.
393-3220

ADOPTED: SEP. 21, 2020 REVISED: FILE NO.: 0552 STD DWG **0552**

STD DWG **0552**