

NOTES:  
SIGN TO BE PLACED AT ALL TRACK ENTRANCES TO  
REMOTE CONTROL YARDS.

SIGNS ARE TO BE PLACED ON THE FIELD SIDE AT  
THE CLEARANCE POINT OF TURNOUTS ENTERING  
REMOTE CONTROL YARDS.


SEE STD DWG 0599 FOR MOUNTING INSTRUCTIONS.

**UNION PACIFIC RAILROAD  
ENGINEERING STANDARDS**

**REMOTE CONTROL  
LOCOMOTIVES SIGN  
(GENERAL)**

STD DWG  
**0554**

ITEM NO.  
**393-3795**

 ADOPTED: SEP. 21, 2020  
REVISED:  
FILE NO.: 0554

STD DWG  
**0554**