



WHEN USING A NUMBERED ZONE SIGN, SLIDE IT UNDER THE REMOTE CONTROL SIGN SO THE BOTTOM HOLE IN THE REOMTE SIGN AND THE TOP (ONLY) HOLE IN THE ZONE SIGN SHARE THE SAME BOLT.

**NOTES:**

1. SIGN SHALL BE PLACED AT ALL TRACK ENTRANCES TO REMOTE CONTROL ZONES.
2. WHERE REMOTE CONTROL ZONES BEGIN AT TURNOUTS, SIGN SHALL BE PLACED AT CLEARANCE POINT ON THE FIELD SIDE OF THE TRACK.
3. WHERE MORE THAN ONE RCL IS WORKING IN A YARD, ZONES ARE TO BE ESTABLISHED AND NAMED "ZONE 1", "ZONE 2" AND SO ON. NUMBERED ZONE SIGNS SHALL BE ADDED BELOW THE TYPICAL REMOTE CONTROL SIGN AS SHOWN.
4. SEE STD DWG 0599 FOR MOUNTING INSTRUCTIONS.

0556  
STD DWG

ITEM NOS.
REMOTE SIGN 393-3805
ZONE SIGN 393-3806

<b>UNION PACIFIC RAILROAD ENGINEERING STANDARDS</b>	
<b>REMOTE CONTROL WARNING SIGN</b>	
	ADOPTED: SEP. 21, 2020 REVISED: FILE NO.: 0556
STD DWG	
<b>0556</b>	