

Manufacturers of Rail Safety and Track Repair Products

Aldon Company, Inc. | 3410 Sunset Avenue | Waukegan, Illinois 60087

RAIL SAFETY RESOURCES

Your Reference for Railroad Safety


This Mini Catalog contains just the basics. For our full line of products visit aldonco.com

If you need technical advice email e-rail@aldonco.com or call us at 847.623.8800


Safety Posters

For Free Catalog or Posters Contact Us:

847.623.8800 | e-rail@aldonco.com | aldonco.com



INDUSTRIAL RAIL YARD HAZARDS 13" x 19" POSTER



BASIC SPUR TRACK SAFETY 11" x 17" POSTER

Universal Handle for Track Gauges & Levels



The light-weight durable design allows rail workers to safely use any track gauge without having to constantly bend over. It easily attaches to most handheld gauges or elevation tools using clamps or thumb screws. Gauges, Levels and Flags sold separately.

4022-28 (Handle Only) 4022-29 Red Flag



Track Gauges & Levels



Our rigid aluminum gauges and levels now provide an easy and accurate way to read and take measurements during track maintenance. Each gauge or level has a lasered on scale for checking the following:


- Track Gauge
- Guard Check Gauge
- Flangeway
- Limits for Class 1, 2, 3, 4, 5 Tracks

Laser engraved Levels and Gauges include: 4022-01, 02, 03 & 07.





Tank Car Lid Saver



The Tank Car Lid Saver is designed to prevent manway lids and valve housing lids from closing. A powerful magnet prevents it from falling inside or off the tank car.

4020-22 Steel



Working with flammable liquids.

Use our spark-proof aluminum version.

4020-24 Aluminum

Tank Car Lid Saver Bracket



The lid saver bracket provides a convenient place to store your Tank Car Lid Saver when it's not in use. The band clamps provided allow for easy installation to handrails on tank car platforms.

Magnetic Rail Top Distance Counter



Distance counter can hold up to two spray cans and is equipped with a powerful magnet. The magnet keeps the counter attached to the rail when not in use. The rail guide plate is designed to keep the

counter on the rail while taking measurements. Easy to read dial shows in "feet" and can measure up to 10,000 feet.

4024-10



Bender Frame Block



The Bender Frame Block is designed to hold any rail bender frame level with rail. Its adjustable base allows it to work with any size rail.

4021-23

AL-200-R Rail Bender



Our AL-200-R Rail Bender is equipped with a light weight 30 ton aluminum hydraulic ram. The hand pump and 6 foot hose allow workers to operate the bender at a safe distance. Each ram has a lasered on scale.



Car Shaker Lifting Tray



The Car Shaker Lifting Tray allows two employees to safely lift heavy piston style railcar shakers into hopper car pockets. Its all aluminum construction makes it light weight and ergonomic design allows for easy installation in tight unloading zones.

4026-01



HD Polyethylene Wall Scraper



The aluminum paddle has a 1/2" thick polyethylene plade that will not bend or flex making the unloading process easier. The paddle attaches to 6 foot long aluminum pole sections that snap together, giving the worker a long reach.

4024-09 Paddle **4023-08** Pole



51A Switch Stand Safety Plate



The 51A switch stand safety plate is designed to keep 51A switches in operation if the pin attaching the crank to the switch stand fails.

Gladhand Lockout



Designed to keep gladhand couplers disconnected.

Padlock not included.

4024-305

Standard Gladhand Gasket



Gladhand air hose gasket. Standard gasket #739882

Gaskets sold separately.

4024-15

Magnetic Rail Car Flag Holder



Attach to any freight car or locomotive when blue flag protection is needed. This aluminum flag holder has a powerful 6" magnet that keeps it secure to the side of any car.

Flags sold separately.

WHEEL CHOCKS - Cast Steel with Spurs



Railcar brakes are not enough to hold a car steady.

Always chock both ends of car after brake is set.

Use chocks on flat track.

Aldon® steel chocks have replaceable rail-biting steel spurs that provide superior holding power & longer life. (Item # 6008)

Standard Chocks

Single Chock (11" handle)



4011-09 (D) Exposed Rail (shown) **4011-10** (D-1) Flush Rail

Double Chock (11" handles)



4011-03 (B) Exposed Rail (shown)

4011-04 (B-1) Flush Rail

4011-05 (B-2) Exposed Rail

w/tension clamp, load binder & padlock

Single Chock with Flag (28" handle)



4011-01 (A) Exposed Rail (shown) **4011-02** (A-1) Flush Rail

Double Chock with Flag (28" handles)



4011-06 (C) Exposed Rail (shown)

4011-07 (C-1) Flush Rail

4011-08 (C-2) Exposed Rail

w/tension clamp, load binder & padlock

Ergonomic Chocks

Single Chock with Flag (44" handle)



4011-14 Exposed Rail (shown) **4011-15** Flush Rail

Double Chock with Flag (44" handles)



4011-16 Exposed Rail (shown) **4011-17** Flush Rail

WHEEL CHOCKS - Urethane





Hold railcars steady under high-vibration and dynamic loading or unloading.

Spark-Proof and resistant to most chemicals.

Never get stuck under a wheel.

When it's time to move the railcar, just roll right over the chock with the power of the locomotive.

Chocks mold to wheel and rail for superior holding power.

Ribbing squeegees out water and dirt from rail surface to increase holding power.

See the chock tests video at aldonco.com

Rail Sizes 90 -142 lbs./yd. | Wheel Diameter 26"- 48"

Heavy Duty Double Chock



4011-40 Exposed Rail (shown) **4011-41** Flush Rail

Heavy Duty Single Chock



4011-42 Exposed Rail (shown) **4011-43** Flush Rail

Magnetic Chock Holder



4011-46 Rare earth magnet will not slip.

Additional Wheel Chock Products

Car Stopper Wheel Chock



Bring slow-moving car to a stop by thrusting urethane wedge several times in front of car wheel.

4011-11 Wedge with 5' PVC Handle **6003** Replacement Wedge

Nine Lives Wheel Wedge



Do not use to chock cars being loaded or unloaded.

Chock idle railcars

on storage tracks.



Sign Holders

The Mouse Trap



Foot-operated hinged sign holder raises and lowers sign. Sign plate can be installed to fall face up or face down. Lockable. Lock not included.

4015-95

Spur Track Guardian



Spur Track Guardian Package

- Hinged Sign Holder (hand-lifted or foot-operated).
- 2. Blue sign, your choice of wording.
- Flashing Blue Solar Light. 6-LED light. Shock-proof and NEMA-4X rain and dust proof. Gravity switch (light turns off at 45° angle).

4015-93 Hand-lifted hinged holder, sign plate, solar light.

4015-122 Foot-operated sign holder, sign plate, solar light.

Flashing Blue Solar Light also sold separately. **4015-135**



Magnet Base Sign Holder





Powerful rare earth magnets hold sign in place, even in high wind.

Flush or exposed rail track.

4015-54

Spike Down



Base is spiked to tie. Sign holder folds down in either direction. Two track spikes included. Lockable. Lock not included.

4015-06

Spear Point



Hammer 12" long spear point into the ground using the included hammer punch.

4015-188

Flag Holders

Rail Clamping



Steel holder clamps to rail head. Twin sockets for 7/8" dowel staff.

4015-23

Magnetic



Wind-proof magnetic base for exposed or flush rail. Twin sockets for 7/8" dowel staff.

4015-55

Flags for all holders are sold separately.

Rail Clamp-Ons

Clamp-On



Steel holder. Clamps to rail head. Easy on, easy off.

4015-01 Non-Locking (shown)

4015-07 Lockina Padlock included.

Aluminum



Double roll bar for stability.

4015-52

Hurricane-Proof



Steel holder with padlock. Withstands 75 mph wind.

4015-10

Magnetic Rail-Top Sign Holder



Rare earth magnet keeps holder in place on the rail.



Accepts 12" x 15" or 18" x 15" sign plates.

4015-230

The Ultimate in Blue Flag Protection

Car Coupler Padlock and Sign Holder





Coupler lock shaft fits flag hole found on all railway couplers. The steel "cage" in the middle of the shaft fits inside the knuckle of the coupler, thus preventing a locomotive or other railcar from coupling to the stationary car.

Padlock included. Sign plate not included. 4015-241

Car Coupler Sign Holder



Gooseneck handle fits into hole in coupler. Sign plate and padlock not included. 4015-03

Standard Blue Flags

Aluminum .080" x 12" x 15". Engineer grade retro-reflective. Single sided.



4015-18-B 6STOP-B



STOP CAR CONNECTED





6SCAW-B





6SMAW-B

6DERAIL-B









4015-18-R 6SMAW-R

6STOP-R

6SCAW-R

Enhanced Blue Flags

Aluminum .080" x 18" x 15". Engineer grade retro-reflective. Single sided. Fits any existing Aldon® sign holder.







7SMAW-B

7SCAW-B

STOP

7SEW-B

7SCC-B

Ν

O

LEAR

AN







7STCC-B

DERAIL

7DERAIL-B

Clearance Signs



Foul Point 12" x 15" 4015-37

WARNING CLOSE CLEARANCE DO NOT RIDE SIDE OR TOP OF CAR

Close Clearance 18" x 24"

4115-42

No Clearance 48" x 6"

4115-37

Nylon Flags

Nylon Flags with Wood Dowel Handle 12" x 15". 18" wood dowel staff.



4015-91 Orange

4015-92 White

4015-21 Yellow 4015-22 Green

4015-20 Red

4015-12 Blue

4015-120 Yellow/Red

Locomotive Cab Signs

Magnetic Signs

Aluminum sign with wind-resistant rare earth magnetic tab.

Printed on both sides (reflective lettering). Other wordings/colors available.







4015-98

81/2" x 15" 4015-96

Locomotive Handrail Blue Flag Holder

Sign holder easily bolts together. (7 feet tall)

Hooks to handrail near cab.

Two-sided sign plates 12" x 15" x .080" aluminum.

"STOP MEN AT WORK" (blue) furnished.

Specify if another wording is desired.



UPRR SIGNS

Private Property Signs



Private Roadway Crossing/No Trespassing Sign. Made to UPRR STD DWG 0521

393-3510



Private Property/No Trespassing Sign. Made to UPRR STD DWG 0528

393-3651

Emergency Sign



Report Problem Or Emergency Pre-Printed DOT # Sign. Made to UPRR STD DWG 0520A

393-1356

Derail Sign



18" Diameter Purple Derail Target. Made to UPRR STD DWG 2100

557-7669

Warning Signs



M

End of Track Sign. Made to UPRR STD DWG 0513A

393-1546



393-1565

End of UPRR Operations Sign. Made to UPRR STD DWG

393-0007

Signal Sign



Whistle "W" Sign. Made to UPRR STD DWG 0543

393-1685

Clearance Sign



Danger Not Sufficient Clearance Sign. Made to UPRR STD DWG 0507

393-1264

Additional UPRR signs can be found at aldonco.com

Crossing Signs

Cross Buck (Hi-Intensity)



2 blades when assembled form 34" x 34" span. Each blade is .080" aluminum 9" x 48". (MUTCD #R15-1)

4015-74

R.R. Advance Warning (Hi-Intensity)



30" diameter (MUTCD #W10-1) 4015-76

STOP 30" Hi-Intensity, Retro-Reflective



30" Octagon (MUTCD #R1-1) .080" Aluminum

4015-75

Bracket



Aluminum bracket for 2-3/8" diameter pipe. Sold in pairs. Use in pairs. (One pair per Cross Buck set)

4015-199



Aluminum bracket for 4" diameter pipe.
Sold in pairs. Use in pairs.
(One pair per Cross Buck set)
4115-96

STOP 24" Engineering Grade



24" Octagon Stop Sign .080" Aluminum **4015-196**

Blank Red (Stop)



24" Square .080" Aluminum Scotch-lite reflective facing.

4115-44

Derail

Round



16" Diameter BNSF Style #28

4115-153 Double-sided **4115-155** Single-sided

Vertical



36" x 6" **4115-41**

Red Vinyl Magnetic Markers



Reflective red vinyl marker with magnetic backing. Place on web or base of rail. SIZE: 2.75" x 12"

DEFECT

Solar Powered Flashing Lights

Flashing Solar Blue Light w/Bracket

Solar-powered blue flashing light includes mounting bracket to attach to any square or flat sign holder. Shock proof and NEMA-4X rain and dust proof.
Gravity switch (light turns off at 45° angle).
Specify standard or derail bracket when ordering.



Flashing Solar Combo Lights w/Bracket



4015-135 Standard

4015-135D Derail



Flashing blue light with flashing white light to illuminate the sign plate.

Brilliant LED lights are visible for over a mile. Shock-proof and NEMA-4X rain and dust proof.

Gravity switch (light turns off at 45° angle). Shown with magnetic base sign holder (4015-54 and 6SMAW-B sign). Sold separately.

4015-205


Car Side Magnetic Solar Light



Flashing Blue Light fully recharges with two hours of sunlight or eight hours of cloudy skies. On/Off button. Gravity switch turns light off when tilted 45° or more.

Magnetic/Bolt-On Surface Mount

6 LED light flashes 60 times per minute. Visible for a mile. Operates 8 consecutive nights without recharging.





Fully recharges with 2 sunny hours or 8 cloudy hours.

External on-off push button conserves battery. Gravity switch disconnects light when light is turned to 45°.

Blue

4015-25 Magnetic **4015-31** Bolting

Amber

4015-35 Magnetic **4015-57** Bolting

Magnetic Bracket

Red

4015-33 Magnetic **4015-34** Bolting

Clear

4015-58 Magnetic **4015-59** Bolting



Bolt-On Bracket

Magnetic Base Solar Lantern



60 lb. pull magnet keeps lantern secure.
Operates up to 22 nights on full battery charge.
Use in upright position.
Turns off when lantern is titled 45° or more.

4015-180

Battery Powered Lights

LED Clip-On / Stick-On Lights

Clip to vest or belt or use magnetic base. Uses single "D" cell battery (not included). Height 4-1/2" tall.

For greater brilliance and reduced battery draw.

4015-194 Blue



Magnetic Mini-Light

Magnetic base/steel clip for all sign holders, except 4015-02, 4015-03, 4015-04, 4015-241, 4015-188, 4015-230.



4015-32

Uses CR2032 Coin Battery (included).

Pocket Lights

Small enough to slip into your pocket. 4 LED light visible up to 2 miles. Magnetic base and belt clip. Uses two AA batteries (not included).



4115-115 Red

4115-114 Blue

4115-117 Amber

Trainman's Lantern

Select signal beam or spot beam by flipping switch. Uses one 6-volt battery. (Battery not included.)

4115-03



LED Barricade Lights



7 inch diameter. Lexan lens uses two 6-volt batteries (not included). On-off switch and photo-electric cell. Flashes 60 times/min. Battery case bolts to any sign holder or Aldon® Chock Light Bracket.

Bolt-On Barricade Light - Blue

For all sign holders, except 4015-03 and 4015-04 Uses two 6-volt batteries (not included).



4115-01

Magnetic Barricade Flasher - Blue

100# Pull magnetic base. Uses two 6-volt batteries (Batteries not included.)

4115-13



Railcar Motion Detectors

Warning Light and Horn



Mounts in the hole on car coupler. Car movement activates flashing light and horn. Uses 8 AA batteries (in



8 AA batteries (included). Enclosure is rain-proof and dust-proof.

One-Way Left Throw Derail



Suitable for all locomotives and freight cars.

10 mph or less

4014-01 (Manual Lift Sign)

One-Way Right Throw Derail



Suitable for all locomotives and freight cars.

10 mph or less

4014-02 (Manual Lift Sign)

Two-Way Freight Car Derail



Suitable for freight cars and 4-axle locomotives.

5 mph or lessNot for use with 6 axle locomotives.

4014-03 (Manual Lift Sign)

Two-Way Locomotive Derail



Suitable for 6-axle and 4-axle locomotives and freight cars.

10 mph or less

4014-18 (Manual Lift Sign)

One-Way Left Throw Derail



Suitable for all locomotives and freight cars.

10 mph or less

4014-10 (Pop-Up Sign)

One-Way Right Throw Derail



Suitable for all locomotives and freight cars.

10 mph or less

4014-12 (Pop-Up Sign)

Two-Way Freight Car Derail



Suitable for freight cars and 4-axle locomotives.

5 mph or less

Not for use with 6 axle locomotives.

4014-14 (Pop-Up Sign)

Two-Way Locomotive Derail



Suitable for 6-axle and 4-axle locomotives and freight cars.

10 mph or less

4014-20 (Pop-Up Sign)

SaberTooth® Portable Derail Protection

Formed-steel housing • Tool free installation • Tie-biting anchor hooks. U.S. Patent #7,753,317





Safety Hook. If brace bar notch should slip off tie plate, hook bites into tie. Prevents derail from slipping.

Single-Direction



For all locomotives and all freight cars. Rails 90-142 lbs./yd.

10 mph or less

4014-06-S Left Throw (shown)

4014-07-S Right Throw

Two-Direction



For all locomotives and all freight cars. Rails 100-142 lbs./yd. 10 mph or less

4014-08-S For 4-axle

locomotives and freight cars. Rails 100-142 lbs./yd. 5 mph or less

4014-09-S (shown)

Replacement Derail Sign Plates

Reflective 10" diameter round, .080" aluminum. Printed on both sides.



DERAIL

4015-71 Blue

4015-72 Red

Padlocks

For derails, switch stands, and other rail equipment.

4124-97 Steel Leaf



4124-318

Solid, Plated H-11 Style

MoonSign



18" diameter White retro-reflective facing 2 sided.

Sign plate fits any Aldon® hinged or portable derail sign holder.

4015-185

4124-319





Shackle Dimensions

Diameter	Inside length	Inside width				
3/8"	2-1/2"	15/16"				
7/16"	1-5/8"	3/4"				
7/16"	11/16"	3/4"				
	3/8" 7/16"	3/8" 2-1/2" 7/16" 1-5/8"				

Aldon® Switch Cube® Indicator



A BIG IMPROVEMENT IN SWITCH TARGETS.

Workers can see at a glance how a switch is lined with no guesswork.

Cube can be adjusted square to rail.

See video on website for more details.



Facing Point



Trailing Point

Double Yellow (Solar Powered Illuminated)

Red Stop (Solar Powered Illuminated)

Double Yellow (Standard)


















4015-164 Left Turnout

















4015-165 Right Turnout

Red Stop (Standard)

















4015-160 Left Turnout

















4015-163 Right Turnout

4015-163-I Right Turnout

4015-160-I Left Turnout

Additional Switch Cube® indicator options at aldonco.com

Norfolk Southern & Conrail Switch Targets

Mounting Hardware Included for NS & Conrail Targets



Low stand target per NS print #968478-0. Mast included.

4015-310



9" diameter low stand target per NS print #009884-0.

4015-311

14" diameter target for intermediate stands per NS print #005783-0. **4015-312**



Low stand target per Conrail print #289518-0.

4015-313



Low stand target per Conrail print #295690-0.

4015-314

Intermediate or high stand per Conrail print #73917-C. **4015-317**

Union Pacific Switch Targets

These switch targets are made exactly to Union Pacific STD DWG 2100



10" Diameter Red Target Item No. 557-7713 (1 pc.) 5" x 10" Green Target Item No. 557-7599 (2 pcs.)

18" Diameter Red Target Item No. 557-7758 (1 pc.) **5" x 18" Green Target** Item No. 557-7603 (1 pc.)

4015-324

Replacement Switch Targets

Racor Targets



4015-206 4015-207 For 22E and 36E stands.

New Century Targets




4115-166 4115-174 For 50A, 51A, 51B stands.

National Trackwork Targets



4115-164 4115-173 For 1004 and 1004 ARS stands.

CLEARANCE POINT MARKERS



Don't let this happen at your track switch.

Help prevent collisions with passing traffic by installing Track Clearance Markers on both converging tracks. Bright colored fade-resistant urethane cone or slab markers are visible day and night.

Urethane Markers (Exposed Rail)



Urethane clearance markers tell workers how far they can park a railcar near a switch.

4015-144 Yellow Exposed Rail **4015-242** Orange Exposed Rail

Urethane Markers (Flush Rail)



Magnetic Rail Web Markers



Fits rails 90-142 lbs./yd. 2.375" x 12". Flexible plate with magnetized back and engineer-grade reflective yellow facing.

4015-248 Blank

4015-255 Secure Cars

4015-256 Check Clearance

Low-profile bright yellow urethane marker to indicate parking limits on tracks encased in concrete or asphalt.

Marker is 36" long by 6" wide and 1" thick.

4015-146 Asphalt (12" drive spikes)

4015-156 Concrete (lag bolts and anchors)

Other Ways to Use Track Clearance Markers



End-Of-Track Warning



Advance Derail Notice



Loading/Unloading Zones

HOPPER CAR GATE AND HATCH OPENERS

Gatemaster Torque Wrench



For tough-to-open gates and multiple gates to open

Gatemaster I

The output torque is sustained until the gate opens or the operator releases the torque.

4020-05



Gatemaster II

Adding an "assistant" torquing unit to the Gatemaster reduces input handle effort needed to achieve full 3,200 lb · ft output.

4020-06



Hatch Key® Pry Bars

Save your back and your fingers. Stubborn hatch covers yield to the leverage in our specially shaped bars.

Standard Duty



Caution: Worker should be secured to fall protection cable while using Hatch Key® Pry Bar.

4020-16 Standard Duty

Heavy Duty



Caution: Worker should be secured to fall protection cable while using Hatch Key® Pry Bar.

4020-17 Heavy Duty

Turning Bar



Six feet long and made of alloy steel, with an angle at one end to clear the side of car.

Operator should not jump or stand on the bar.

Brake Sticks Short/Medium/Long Reach



High quality Brake Stick telescopes and locks.

User can tighten and release brakes, align car coupler knuckles, operate angle cocks, and re-set end-of-train warning devices.

4123-104 "Short" 24"-42" **4123-154** "Med." 49"-81" **4123-105** "Long" 59"-104"

Brake Sticks with Magnetic Handle

The strong neodymium magnet allows you to attach the brake stick to any locomotive or car while performing other tasks.



4123-152 "Short" 24"-42" Magnetic Handle **4123-155** "Med." 49"-81" Magnetic Handle

4123-153 "Long" 59"-104" Magnetic Handle

4123-156 73" Fixed Length Heavy Duty

Light Weight Brake Sticks

The carbon fiber construction and non-slip Kevlar cover makes it light weight and durable. Each brake stick is equipped with three strong magnets.



4123-159 48" Fixed Length Handle **4123-160** 60" Fixed Length Handle **4123-158** 67" Fixed Length Handle **4123-161** 75" Fixed Length Handle

Manual Car Mover



The tried and true way to move one railcar short distances. Car mover multiplies worker's downward handle pressure to lift and nudge the wheel slightly forward. **Use on flat track only.**

Do not use car mover foot as a wheel chock.

4017-01 Wood handle

4017-02 Replacement Wood Handle (54")

4017-03 Aluminum Handle

Permanent and Temporary Car Stops

- Rail size 80-142 lbs. Limit 1-2 cars.
- Flat track only at a slow speed 2 mph max.
- Exposed rail. (Flush Rail Contact Us)
- Provide ample space between car stops and object to be protected.
- Use a signalman as cars approach stop or post. Repeated impacts will weaken stops and posts.

CS-2 Car Stop



Portable for temporary use on exposed rail. Wedge secures twopiece stop to rail. Use in pairs.

4016-03

CS-3X Locking Car Stop



Permanent installation on exposed rail. Use in pairs.

4016-05-L Left **4016-05-R** Right

CS-4 Severe Duty Type



Recommended for spur tracks where more protection is needed than a conventional car stop can provide. Use in pairs.

4016-06

Two-Way Flush Rail Car Stops



4016-26

Designed for flush rail applications. Easy installation without cutting away your concrete.

Tool-free installation and removal (simply drop-in/lift out.

Can stop one car at 3 mph, and up to three cars at 1 mph.

Steel mounting plates bolt directly to your concrete. Mounting hardware included.

Sold as single units. Use in pairs.

Flush Rail Car Stop Cart



Designed for installing and removing flush rail car stops.

The cart allows one worker to easily maneuver car stops in any elements while only having to lift 30 lbs.

Straddle-Type Freight Car Rerailers



The most practical design. All wheels are rerailed with one placement of rerailers.

Rail Size 90-142 lbs./yd.

4018-01-L (H-7) Left **4018-01-R** (H-7) Right

Rail Size 70-110 lbs./yd.

4018-02-L (E-6) Left (shown) **4018-02-R** (E-6) Right (shown)

Chain and hook holds rerailers securely to rails.

McCarty Freight Car Rerailers



Two-way rerailing for locomotives and heavy freight cars. Cast-steel rerailers straddle two ties and hook to the rail head. Stout carrying handles keep each rerailer from moving during rerailing. Used in pairs.

Rail Size 90-130 lbs./yd.

4118-14-I Inside **4118-14-O** Outside

Rail Size 131-152 lbs./yd.

4118-15-I Inside **4118-15-O** Outside

"Burlington" Style Freight Car Rerailers



Double-ended "Burlington" style rerailers are locked to the rails by clamps and wedges and will not slip or kick out during rerailing. One "Inside" and one "Outside" make a pair.

Rerailers are reversible in direction and exchanged in position to suit different derailed wheel situations. For use with standard size cars and locomotives.

Rail Size 100-142 lbs./yd.

4018-04-I Inside **4018-04-O** Outside

Replacement Clamp & Wedge


Sold individually. 6135 Clamp 6134 Wedge

4018-24 Super-Duty Wedge




ALDOR® Boxcar Door Openers

Adjustable-Length ALDOR — Steel



4020-02 Fits fork blades up to 5" wide. For wider blades contact us.

Force is parallel to car door so no damage is done to forklift or car door. Forklift and operator remain safely out of the way of the door at all times.



Boxcar Door Openers are Custom Made. Please Request a Sizing Form.

Fixed-Length ALDOR — Steel



4020-14 Fits fork blades up to 5" wide. For wider blades contact us.

Accessories





4020-20 Reversing Chain (Sold Separately)

Replacement Parts





6747 Aldor Chain and Hook Assembly (Included with ALDORS)

Roadmaster Rolling Gauge Reader



Rolls through switches and rail crossings without stopping.

Continuous gauging with 2" clearance above rail. Easy rolling thanks to 24 steel roller bearings which ride on the top and on the gauge side of the rail.



Read gauge changes as you walk.

Reversible push handle allows change of direction.

4022-14

Track Gauge Spreader



One end of the head-of-rail Spreader model has a double jaw, one of which is offset to lift Spreader above switch point or heel block.



Gauging range 16 inches.

4023-50 Head of Rail (Non-Insulated)

4023-51 Base of Rail (Non-Insulated)

4023-52 Base of Rail (Insulated)

Grabs rail head or base to pull or push rails into desired gauge.

Gauge Control Rods



A pair of iron jaws at each end of the double-ended gauge rod grip the rail base to hold the rails to gauge and keep the rails upright against wheel pressure. Gauge rods are not painted yellow. Images are colorized for clarity.

4127-01 (Single End Non-Insulated)

4127-01-I (Single End Insulated)

4127-02 (Double End Non-Insulated) **4127-02-I** (Double End Insulated)

Adjustable Aluminum Level & Gauge



Measure two inches of gauge variation to within 1/16". Slide rule action and large type scale.

Gauge setting can be locked with thumb screw. Measures cross elevation from 1" to 7" with 1/8" accuracy.

Two piece 56" - 58" Gauge Range **4022-07**

Fixed Gauges & Track Levels

Standard gauge or any custom gauge desired. Imperial or Metric.



Aluminum Track Level **4022-01**





Steel Pipe Gauge **4022-05**

"SPOT-CHECK" Magnetic Laser Gauge



Aluminum bracket with two rare-earth magnets holds Spot-Check on rail. Two adjusting screws raise or lower laser beam 20° with laser range of 135 feet. Screen displays current and previous readings.





4022-26

Stringline Rail Curve Measuring Tool



Measure track curvature or visually judge the straightness of straight rail. Steel paddles lock to rail head.

The custom 12" ruler measures the space between the rail head and the red-marked midpoint of a 62' cord.

Each inch of space between rail and string equals one degree of curvature.

Accuracy of measurement is +/- 4%.

TRACK INSPECTION AND MAINTENANCE

Rail Pull / Re-Gauger



Bring rails back into gauge after a derailment so rerailing can proceed. Cars can temporarily pass over Rail Pull saddles until rails can be re-gauged. Solid formed alloy steel plate.

No welded joints to crack. **4023-74**

Wrench and Socket Kit for Rail Pull

1/2" square drive ratchet wrench and 1"8-point impact socket.

4023-78



Two-Piece Miracle Cart

Welded Aluminum 5,000 lb. load capacity.

Each cart half weighs 49 lbs. 48" square expanded aluminum grid. Parking brake. 6" diameter insulated aluminum wheels.

4025-03

Two-Piece Steel Push Cart



Track Bolt Ratchet Wrench Handle is 38" long, with

1"square drive.

1" Square Drive Sockets 4124-140 1-5/16" 8 pt.

4124-143 1-1/2" 8 pt.

4124-144 1-9/16" 8 pt. **4124-147** 1-3/4" 8 pt.

4124-149 1-7/8" 8 pt.

Wrench only: **4123-112**





4025-02

5,000 lb. capacity.

Each cart half weighs 93 lbs.

48" x 48" deck is non-skid expanded steel.

6" diameter insulated aluminum wheels.

Parking brake.

TRACK INSPECTION AND MAINTENANCE

Switch Maintenance

GLIDEX Liquid Switch Stand Lubricant

Not soluble in water: Resists rain and snow. No build-up of dirt or dust on switch stand moving parts. Non-toxic synthetic

ingredients. GLIDEX can be brushed, sprayed, or poured on switch points, throw rods, etc. 5-gallon bucket.

4123-128



Track De-Icer

Prevents snow and ice from clogging rail and switch points. Non-flammable and dilutable. Sold in 5 gal. containers.

4123-129



Sprayable Graphite Grease


Keeps switch points and switch rods from rusting and sticking. Flammable material-shipping regulations apply. 4 gals. /case.



4124-106

Only ships by motor freight under hazmat class.

Inspection & Maintenance Guides







Industrial Track Inspection

Information to keep your industrial siding running smoothly and safely.

Request your free copy at **Aldonco.com**

Applicators

Lubrication Spray Tank

Keep all moving parts of a switch operating smoothly. Spray tank holds 3 gallons of lubricant.

4123-79



Lubrication Brush

46" handle and long-bristle poly brush.



Railroad Spill Containment Pan



Polyethylene pan is placed on rail beneath tank cars and hopper cars. The pan holds up to 50 lbs. of drips as hoses are connected. Do not use with acids.

4124-29 With Drain Holes

4124-30 Solid Pan

Blue Boat Spill Pan



For plastic pellets and other materials. Molded polyethylene pan is 29" long x 14" wide by 10" high. Screened drain in bottom lets liquids pass through.

4124-310

Absorbent Track Mat



Provides absorbency and drip protection under railcars for a wide variety of petroleum-based products.

4123-148 59" wide roll (Inside rails)

4123-149 Set of two 19" wide rolls (Field side of rails)

Pneumatic Piston-Type Car Shakers



The piston shaker has a wedge-end which fits all standard covered hopper car side brackets.

4126-01 PCS-3 Car Shaker (Dry, granular materials)

4126-02 PCS-4 Car Shaker (Sticky, damp materials)

Air Brooms



Better than a push broom. Clean up dry spillage and unclog hopper chutes with a jet of high-pressure air.

4124-212 Barrel length 48"

4124-213 Barrel length 36"

4124-214 Barrel length 60"

Rotary Pneumatic Car Shaker

Mounts easily to most standard wedge brackets on covered hopper car pockets. Recommended for potash (fertilizers),

corn, wheat, soybeans,

distilled dried grains, salt, coke, crushed stone, and sand gravel (up to 1/2"). Three sizes available. Wedge & Handle included.

4126-5500 4126-6500 4126-7800

Switch Protection

Switch Point Protector

Protect switch points to reduce derailments.

The sharp ends of switch points are vulnerable to wheel battering.

If a switch point tip gets mangled, it will not lie flat against the running rail. Any gap between the switch point and the running rail will allow a wheel flange to slide in, "pick the point" open, and derail.



For Industrial Spur Switches
To order: Identify your rail size and section.
If your rail size is not shown, contact us.

4123-77

AREMA: 100 LB ARA-A: 100 LB AREMA: 110 LB

4123-77-A

AREMA: 112 LB, 115 LB, 119 LB

4123-77-B

AREMA: 131 LB, 132 LB, 136 LB 140 LB AB: 141 LB

NYC: 127 LB 4123-77-C

ASCE: 85 LB, 90 LB ARA-B : 100 LB PS: 100 LB

4123-77-D

ASCE: 100 LB

4123-77-E

NYC: 105 LB PS: 130 LB

4123-77-G

AREMA: 133 LB

4123-77-H

AREMA: 141 LB

4123-77-I

ARA-A: 90 LB

4123-77-J

AREMA: 130 LB

Switch Security

Switch Point Clamp and Lock

(Rail Size 85-142 lbs./yd.)

Fine screw threads and 3-point handle hold switch point tight against running rail to within 1/32".

Use when making switch stand adjustments. Protect track repair crews and rip track workers.



Padlock not included.

4023-07

Switch Point Lock
(Rail Size 85-142 lbs./yd.)

No threads to rust. Sliding clamp locks in place with padlock. Use when closing a switch to traffic and to prevent a worker from accidentally throwing the switch handle.

Padlock not included.

4023-43



Safety Hook for Switches



4024-303

Takes the place of a padlock to prevent unauthorized movement of a switch.

Formed steel hook with stainless chain can be bolted to tie.
Lag screw included.
Meets FRA Regulation

218.103 (Switch Stand

Securement).



Track and Switch Brooms





Unbreakable aluminum handle with chisel end, poly-bristles.



4023-21

Standard Wood Handle

Wooden handle with chisel end, poly-bristles.

4023-19

Magnetic Tip Track Inspection Tape Measure

Magnetic tip allows one worker to quickly check track gauge.

Color coded overlay scale gives tolerance for out-of-gauge track and cross-checking guard rail and frog spacing for Class 1 through Class 5 track.



4124-316 25 ft. Tape



Rail Benders 60 lb. - 141 lb. Rail

AL-200-H Hydraulic Rail Bender



30-Ton Bender for conventional strength rail.

Use for switch point pockets and rail repairs. Single hook bender frame. Safety chain secures ram/pump unit to frame.

4021-01

AL-200-S Screw-Jack Rail Bender



25-Ton Bender for conventional strength rail.

Use for switch point pockets and rail repairs. Single hook bender frame. Safety chain secures ram/pump unit to frame.

4021-02

Rail Benders 25 lb. - 85 lb. Rail

Curve mine rail and make other rail repairs.

V-shaped bender frame available with 25-ton hydraulic ram-pump or 50-ton ram with remote pump.

25-Ton Hydraulic Ram



Part No. Ram Size Rail Size **4021-06** (2-H) 25-tons 60-70# **4021-07** (3-H) 25 tons 25-60#

50-Ton Hydraulic Ram



Part No. Ram Size Rail Size **4021-09** (2H-50) 50-tons 60-85# **4021-10** (3H-50) 50-tons 25-60#

Industrial Service (Rail Size 90-141 lbs./yd.)



A light-weight skid, useful as a wheel chock on industrial sidings, and to alert an engineer when pushing a string of cars into a dead-end string.

4016-09 S-78 Rail Skid



For light to average weight railcars, use as a car stopper and wheel chock.

4016-10 S-61 Rail Skid

Railroad Service (Rail Size 100-141lbs./yd)

For industrial use, skid can be used to stop 1 to 4 freight cars moving at 1 to 2 mph on flat track only. For exposed rail only, skid will not lie flat on rail encased in pavement. Features deep "pocket" to capture car wheel. High back keeps wheel from jumping over.

4016-12 S-87 Rail Skid (Yellow)

4016-12-0 S-87 Rail Skid (Orange)



Chocking Skids for Flush/Exposed Rail

Locomotives

Locomotive air and hand brakes must be applied as soon as wheel has mounted skid. The skid alone will not hold a locomotive steady. Not recommended for grades, as skid may not hold the load.



Flush Rail Locomotive Chocking Skid **4016-09-L**



4016-09-R



Exposed Rail Locomotive Chocking Skid

4016-13

Freight Cars

Handy for chocking freight cars on flat track, it may be necessary to chock the other end of the car with a wheel chock.

Not recommended for grades, as skid may not hold the load.



Flush Rail Left 4016-22-L



Flush Rail Right 4016-22-R

T-Wrenches for Sockets



T-Wrench image is colorized for clarity.

Useful where 200 lb · ft or less of torque is needed to loosen or tighten manway cover bolts.

Square drive 1 inch.

4024-157 Steel

4024-195 Aluminum (Spark Resistant)

Tank Car Sockets

1" square drive

4" bolt clearance. Bronze or Steel. Available in various nut sizes, hex or square.

Steel



Max Torque Rating 1500 lb • ft

Bronze



Max Torque Rating 500 lb · ft Not for impact use.

See website for sizes offered.

Tank Car Safety Gate

Fits over gap in railing at top of tank car access ladder.

Formed aluminum panel drops over railing ends and locks securely in place with safety pins. Red reflective safety tape provides an additional safety measure.



4024-283

Tank Car Pry Bars



Maximum leverage to open heavy manway covers.

Five foot handle. Rocker base. Much better than using a crowbar!

4020-18 Steel **4020-19** Aluminum (Spark Resistant)

Tank Car Wheel Block

High-security wheel blocking. Clamps grip rail head through wedge action.



Use on flat track only.

Do not use for impact stopping.

Use one chock at each end of car after brake has been applied.

4016-01 (CB6-A) For rails 60-104 lbs.

4016-02 (CB6-B) For rails 105-175 lbs. (shown)

Hose Cradle



Broad polyethylene base supports hose. Velcro belt keeps hose steady during unloading.

Dimensions: 13" High x 19" Square

4124-312

Hanging Tool Tray



4024-282 Tool Tray with Lid **4024-280** Tool Tray without Lid

Our Hanging Tool Tray (With Lid) provides additional protection.

Keeps small tools safe and dry from the earth's natural elements when working on tank and hopper cars.



TRUCK DOCK SAFETY - Trailer Stabilizers

Adjustable Spin Top Steel

Weight




Item 4013-13 39-1/2"-51" Service Range Static Capacity 100,000 lbs. Lifting Capacity 40,000 lbs. Top Cap 8" Dia. Wheel Size 10" Dia. Handle Length 20" Overall Width 17-5/8" Overall Length 26-5/8" **Base Width** 17-5/8" Base Length 16"


100 lbs.



Always use two stabilizers at the front of each trailer. Trailer must be secured with dock lock or wheel chocks.



Bad Support



Good Support

Dolly Pad

On soft ground use wood pads under the landing legs. Install a pair of jacks at the front end.

4024-04 17" sq. x 3" high






Each jack is equipped with a 20" handle and 10" diameter rubber wheels that make maneuvering the jack easy.

TRUCK DOCK SAFETY - Truck Wheel Blocks

A Wheel Block for Every Dock Situation

Feather-Light Aluminum



Walk-In Aluminum Wheel Block



Cast Iron





Resilient



7 Easy to Install feather-light aluminum. Easy for the driver to see from the cab.

			Wh	Wheel Block Size		
Key	Description	Part Number	W	L	Н	
1	LWC Block	4012-01	6"	8-3/4"	6"	
2a	LWC Block w/Flag	4012-13	6"	8-3/4"	6"	
2b	HWC Block w/Flag	4012-02	7″	10-3/4"	8″	
3	HWC Block	4012-03	7″	10-3/4"	8″	
4	AL-95 Block	4012-06	9-1/8"	8″	8-1/2"	
5	AL-96 Block	4012-04	10"	10-1/2"	10-3/4"	
6	RWC Block	4012-05	7″	10"	8″	
7	Walk-In Block w/Flag	4012-11	7″	10-3/4"	8″	
8	HWC Wheel Block & Handle	4012-16	7″	10-3/4"	8"	
9	Walk-In Wheel Block w/Flag & Handle	4012-17	7″	10-3/4"	8″	



8 30" Handle makes installation easy.



9 Double chock w/chain.

Portable Crane Stops



Cushion-Slide Crane Stops

Drag plates allow stop to slide some distance to absorb impact. On smaller sizes of rail, plates may interfere with rail hook bolts — use non-slide crane stops in such cases.

Bumper Contact Type



For crane bumpers (maximum bumper centerline 12" above top of rail). Specify bumper height, rail size, and section.

4016-08

Wheel Contact Type



Specify wheel diameter, rail size, and section.

Stops are cut to fit a specific wheel diameter.

4016-07

Non-Slide Crane Stops

Wedge dogs lock stop to rail head and do not interfere with rail hook bolts. On impact, stops may slide minimally. Tighten bolts frequently.

Bumper Contact Type



For crane bumpers (maximum bumper centerline 12" above top of rail). Specify bumper height, rail size, and section.

4016-21

Wheel Contact Type



Specify wheel diameter, rail size and section.

Stops are cut to fit a specific wheel diameter.

4016-20

For All Crane Stops Use in pairs | Align stops | Do not use at end of crane run. Allow ample distance between crane stops and the object to be protected.

Single or Multiple Crane Operations

Overhead bridge cranes: 1910.179(I)(2)(i)(e)

Where other cranes are in operation on the same runway, rail stops or other suitable means shall be provided to prevent interference with the idle crane.








Protect Workers from Crane Overrun





Isolate a Crane Undergoing Repairs



RAILCAR STABILIZERS AND CAR STANDS



Railcar Stabilizer

For use as secondary support to power lifting jack. Do not use as sole support of car. No worker should stand underneath raised car. Used for unloading railcars to provide stability and prevent them from tipping over.

Custom-made to fit your railcars.

Please request a sizing form (or download from our website).

We will send you a drawing for approval.

Jack height cannot exceed 54"

Maximum screw elevation 6". Load Capacity: 75,000 lbs. Top Cap: 5" diameter. Base: 19" diameter.

4013-01-S Spin-Top Screw

Fixed Height Freight Car Stand

Use as back-up support for power lifting jacks. Do not use as sole support of car.

Base: 19" diameter.
Top: 12" x 131½" square.




Oak Pad for Car Stand

1-3/4" thick x 9-3/4" x 11-1/4"

4024-01-A







In 1904, when Aldon Company was established, our market was limited to the railroads, many of which were headquartered in Chicago. Over the many decades since then, our market has expanded to include rail-using industrial firms in more than 300 different kinds of industries.

Aldon® can provide all the basic rail safety and track repair products that you need in your rail yard.

Give us a call.



Aldon Company, Inc. | 3410 Sunset Avenue | Waukegan, Illinois 60087

PH. 847.623.8800 | FX. 847.623.6139 www.aldonco.com | e-rail@aldonco.com

Follow us on









